




# Respirators and Dust Hazards

# Introduction

- What types of Dust are there?
- Why is Dust Control necessary?
- What are the Health Hazards of Dust?
- How can Dust be controlled?

# What is Dust ?

Dust is – 1 Micron In Size!



# How is Fresh Dust Generated?

Fresh dust is generated by one or multiple of the following:

- Impact
- Abrasions
- Crushing
- Grinding



[This Photo](#) by Unknown Author; not property of Sussex Environmental

# How is Dust Recirculated?

- Release of previously generated dust during such processing operations as:
  - Loading
  - Dumping
  - Transferring
  - Wind
  - Movement of equipment and workers



[This Photo](#) by Unknown Author; not property of Sussex Environmental

# Dust Classification

1. Fibrogenic Dust ( Disease Causing )
  - Crystalline silica (Quartz)
  - Asbestos
  - Beryllium
2. Nuisance Dust
  - Dust that does not contain harmful quantities of asbestos and less than 1% quartz

# Dust Classification by Size

Dust is Classified into TWO size categories


- Respirable Dust
- Inhalable Dust



This Photo by Unknown Author  
is licensed under [CC BY-SA](#)

# Inhalable Dust


- Dust that enters the body, but is trapped in the nose, throat and upper respiratory tract.



[This Photo](#) by Unknown Author is licensed under [CC BY](#)

# Respirable Dust

Dust particles small enough ( less than 10 microns) to penetrate past the upper respiratory tract and deep into the lungs.



This Photo by Unknown Author is licensed under [CC BY](#)

# Why Control Dust

- Occupational respiratory diseases
- Irritation to eyes, nose, and throat
- Skin irritation
- Damage to Equipment
- Impaired Visibility
- Community Relation
- Explosions



[This Photo](#) by Unknown Author; not property of Sussex Environmental

# Health Hazards

The harm dust can cause depends on the following:

- Dust composition
- Dust concentration
- Amount of exposure time
- Particle size and shape

Excessive exposure to harmful dusts can cause pneumoconiosis- a dust related lung disease.

# Dust Related Lung Diseases

## 1. Silicosis

- Caused by Silica Dust

## 2. Black Lung

- Caused by Coal Dust

## 3. Asbestosis

- Caused by Asbestos Dust

Damage from these diseases is **Irreversible!**



[This Photo](#) by Unknown Author is licensed under [CC BY-SA-NC](#)

## ▸ Controlling Dust Exposure- Safer Machinery and Tools


- Fully enclosing dusty processes.
- Local exhaust ventilation/dust collection equipment.
- Tools with dust extraction (vacuum) devices.
- Using water to suppress dust.
- Operator enclosures with an air filtration system.
- Use abrasives other than sand for abrasive blasting

# Wet Dust Control System



[This Photo](#) by Unknown Author; not property of Sussex Environmental

# Additional Dust Control System



[This Photo](http://Bosstek.com) by Bosstek.com; not property of Sussex Environmental

## Controlling Dust Exposure- Safe Work Procedures

- Wetting down dusty work areas or processes prior to work.
- Working upwind of dust sources where possible.
- Posting warning Signs where necessary.
- Limiting Exposure time.
- Training all employees on appropriate work procedures.
- Good housekeeping practices.

# Controlling Dust Exposure - Respiratory Protection

- Fit testing of all employees required to wear respiratory devices.
- Training employees in the proper use of respiratory devices.
- Making sure employees understand the hazards of dust and the importance of respirator use.
- Regular checking and cleaning of non-disposable respirators.

# Reasons for Respirators?

1. Certain Breathing conditions are hazardous to life and lung.
2. The air can be contaminated with: Dusts, Mists, Fumes
3. Toxic Vapors
4. The air can have too little oxygen

**4 Reasons**

[This Photo](#) by Unknown Author is licensed under [CC BY-SA-NC](#)

## How do we control these Airborne Hazards?

First - Use Engineering Controls to eliminate the hazard.

Second - Use Administrative Controls to reduce exposure to the hazard.

Last - Use Respirators as a temporary protective measure until Engineering and Administrative Controls are in place.

# 2 Basic Types of Respirators

## Air Purifying Respirators

- Used to filter out or neutralize contaminants
- Examples: Dust; Organic Vapor

## Air Supply Respirators

- Used when there is a lack of oxygen, when the hazard is unknown or is undetectable by smell or taste.
- Examples: Compressor & Hose; SCBA

# Filtering Respirators

1. Particulates - Dusts, Mists & Fumes
  - New Classes; N, R, P; 95, 99, 100
2. Non-Resistant(Oil), Resistant(Oil), (Oil) Proof
  - Toxins - Organics, Acids, etc.
  - Neutralizing or Absorbing

Filtering Respirators are Hazard Specific  
Don't expect one respirator to protect you from all hazards!

# How long do Respirators last?

- Particulate (Dust) Filtering Respirators
- Change them when the breathing resistance gets high.
- Toxin Filtering Respirators
- Change when you first smell or taste a contaminant (Break-through)

# Health Conditions that Interfere with Respirator Use

- Heart Conditions
- Asthma or other breathing problem
- Claustrophobia (fear of enclosed space)
- Fast Growth Facial Hair

## Other Conditions that can Interfere with Respirator Use

- Contact Lenses
- Eyeglass Temples (certain types)
- Skullcaps (Beanies)

## Respirators Used at Your Workplace

- How to don your respirator.
- Look at the manufacturer's instructions.
- How to clean & Maintain your respirator.
- How to Self-Fit Test your respirator.
- Not possible with Filter-Face Types
- Positive, Negative Test

# Sampling Methods

**Total Dust-** is analyzed using a NIOSH 0500 Method on a Gravimetric 37PVC 5.0 PW or 25PVC 5.0 PW media cassette for any dust that is able to be inhaled into the upper respiratory system

**OSHA PEL for Total dust is 15 mg/m<sup>3</sup>; ACGIH: 10 mg/m<sup>3</sup>, total dust less than 1% quartz**

**Respirable Dust-** is analyzed using a NIOSH 0600 method on a gravimetric 37PVC 5.0 PW media cassette for any dust that is able to be inhaled into the lower respiratory system and enter the lungs

**OSHA PEL for Respirable Dust is 5 mg/m<sup>3</sup>; ACGIH: 3 mg/m<sup>3</sup>**



Feel free to ask questions or email Susan at  
[Susan.white@mchsi.com](mailto:Susan.white@mchsi.com)